



Service Manual

Freestanding Freezer Upright AFB 6520

Model	AFB 6520	
Version	8504 652 01006	Page
	Technical data	2
	Spare part list	3
	Exploded view	4
	Circuit and Wiring diagram	5

Technical data

Factory Code

CV 096 W

Dimensions

Height	85.0	cm
Width	54.0	cm
Depth	60.0	cm

Capacity

Total		
gross	102	l
net	95	l
Freezing		
gross	102	l
net	95	l

Electrical connection

Voltage	220 - 240	V
Frequency	50	Hz

Power consumption

in 24 hours	0.78	kWh
-------------	------	-----

Freezing capacity

in 24 hours	10	kg
-------------	----	----

Compressor

Type	HQY 80 AA	
Capacity (CECOMAF)	99	W

Refrigerant

Type	R 600 a	
Quantity	30	g


Thermostat

Electronic

Spare part list

Model **AFB 6520**
Service No. **850465201006**
Version **850465201006**

Pos. No.	12NC Code	Description
001 1	4812 464 18159	Traverse, compressor
001 2	4812 525 18014	Guide
002 0	4812 440 98259	Frame, table top
002 1	4812 404 48915	Support
002 3	4812 404 48939	Spacebar
002 4	4812 440 98254	Air grid
011 0	4812 462 18263	Adjust. foot
011 1	4812 462 18254	Foot
040 0	4812 417 19125	Hinge, upper
040 1	4812 226 08004	Pin, hinge
040 2	4812 417 19115	Hinge, lower
101 0	4812 416 19615	Door, freezer
105 0	4812 532 88064	Bushing
105 1	4812 532 88062	Sleeve
105 2	4812 532 88063	Sleeve, left
110 0	4812 498 18347	Door handle
156 0	4812 418 28471	Icecube, tray
176 0	4812 459 18218	Nameplate
191 0	4812 466 68828	Magnetic seal
242 0	4812 418 68329	Drawer, I
242 1	4812 418 68331	Drawer, II
242 2	4812 418 48755	Cover, basket
242 3	4812 418 48754	Cover, basket, with serigr.
301 0	4812 214 79313	Control panel, el. set
403 0	4812 360 38946	Compressor, HQY 80 AA
491 0	4812 462 28261	Cover
491 1	4812 290 88084	Connect. block
614 0	4812 280 38049	PTC-Unit, K100ZF7 (ZF7)
691 0	4812 210 58046	Sensor temper., freezer
740 0	4812 511 48384	Condenser
746 0	4812 511 38276	Evaporator, freezer
746 1	4812 466 28139	Holder, evap. left
746 2	4812 462 28447	Holder, evap. right
746 3	4812 460 98055	Panel
746 4	4812 460 98088	Panel
746 5	4812 404 78705	Cover sensor, freezer
764 0	4819 526 48527	Dryer
781 0	4812 171 58002	Overflood cond.
783 0	4819 526 43046	Tube service
904 0	4812 226 08003	Plug
904 1	4812 462 28558	Cover, screw
904 2	4812 532 88061	Cover



Circuit and Wiring diagram

